

Silicon Labs CP210x USB-to-UART

Installation Guide

UG1033 (v1.0) February 12, 2014

Revision History

The following table shows the revision history for this document.

Date	Version	Revision
02/12/2014	1.0	Initial Xilinx release.

Table of Contents

Silicon Labs CP210x USB-to-UART Installation Guide

Overview	4
Download and Install the Required Drivers	5

Appendix A: Additional Resources and Legal Notices

Xilinx Resources	7
Solution Centers	7
References	7
Please Read: Important Legal Notices	7

Silicon Labs CP210x USB-to-UART Installation Guide

Overview

Many Xilinx evaluation boards and some characterization boards are equipped with the Silicon Labs CP2103 USB-to-UART bridge integrated circuits. This guide explains how to install the drivers for the USB-to-UART bridge.

Download and Install the Required Drivers

1. Go to the Silicon Labs [CP210x USB-to-UART Bridge VCP Drivers](#) download page.
2. Download the virtual COM port (VCP) driver for your operating system to your PC. See [Figure 1](#).

The screenshot shows the Silicon Labs website page for CP210x USB to UART Bridge VCP Drivers. The page includes a navigation menu with 'Products', 'Applications', 'Support', and 'Buy or Sample'. A search bar is located in the top right. The main content area features a breadcrumb trail: 'Silicon Labs > Products > MCUs > USB to UART Bridge VCP Drivers'. The title is 'CP210x USB to UART Bridge VCP Drivers'. Below the title, there is a paragraph explaining the drivers and a link to 'AN197: The Serial Communications Guide for the CP210x'. A 'Download Software' section follows, with a note about updated DLLs. Two tables provide download links for different operating systems. The first table is for 'Download for Windows XP/Server 2003/Vista/7/8 (v6.6.1)' and the second is for 'Download for Windows 2K (v6.3a)'. Both tables have columns for 'Platform', 'Software', and 'Release Notes'. A sidebar on the right contains various support and tool links. A blue button at the bottom right says 'GET THE LATEST DOCUMENTATION UPDATES. Register today'.

Platform	Software	Release Notes
Windows XP/Server 2003 Vista/7/8	Download VCP (3.49 MB)	Download VCP Revision History

Platform	Software	Release Notes
Windows 2K	Download VCP (4.79 MB)	Download Win2K VCP Revision History

Figure 1: Silicon Labs CP210x Driver Download Page

3. Extract the ZIP archive file.
4. Open the extracted file and select the executable file that is compatible with your PC. For example, for Windows 64-bit, select `CP210xVCPInstaller_x64.exe`.

- Step through the guided installer. Accept the license agreement and install the software on your PC. When the software is successfully installed, the dialog box shown in [Figure 2](#) is displayed.




Figure 2: USB-to-UART Bridge Driver Installer

- The next step is to set up a terminal emulator. Continue with the instructions in the appropriate quick start guide. At the appropriate time, you will be directed on the configuration of the terminal settings. If you do not have a terminal emulator, download the Tera Term emulator and follow the installation process in the *Tera Term Terminal Emulator Installation Guide* (UG1036) [\[Ref 2\]](#).

Note: Use of the Tera Term terminal emulator is not required and other terminal emulators can be used. Tera Term is recommended by Xilinx based on its long history as a reliable software product.

Additional Resources and Legal Notices

Xilinx Resources

For support resources such as Answers, Documentation, Downloads, and Forums, see [Xilinx Support](#).

For a glossary of technical terms used in Xilinx documentation, see the [Xilinx Glossary](#).

Solution Centers

See the [Xilinx Solution Centers](#) for support on devices, software tools, and intellectual property at all stages of the design cycle. Topics include design assistance, advisories, and troubleshooting tips.

References

These Xilinx documents provide supplemental material useful with this guide:

1. See the appropriate quick start guide for your Xilinx product.
2. *Tera Term Terminal Emulator Installation Guide* ([UG1036](#))

These external websites provide supplemental material useful with this guide:

3. [CP210x USB-to-UART Bridge VCP Drivers](#)
 4. [Tera Term](#) download page
-

Please Read: Important Legal Notices

The information disclosed to you hereunder (the "Materials") is provided solely for the selection and use of Xilinx products. To the maximum extent permitted by applicable law: (1) Materials are made available "AS IS" and with all faults, Xilinx hereby DISCLAIMS ALL WARRANTIES AND CONDITIONS, EXPRESS, IMPLIED, OR STATUTORY, INCLUDING BUT NOT LIMITED TO WARRANTIES OF

MERCHANTABILITY, NON-INFRINGEMENT, OR FITNESS FOR ANY PARTICULAR PURPOSE; and (2) Xilinx shall not be liable (whether in contract or tort, including negligence, or under any other theory of liability) for any loss or damage of any kind or nature related to, arising under, or in connection with, the Materials (including your use of the Materials), including for any direct, indirect, special, incidental, or consequential loss or damage (including loss of data, profits, goodwill, or any type of loss or damage suffered as a result of any action brought by a third party) even if such damage or loss was reasonably foreseeable or Xilinx had been advised of the possibility of the same. Xilinx assumes no obligation to correct any errors contained in the Materials or to notify you of updates to the Materials or to product specifications. You may not reproduce, modify, distribute, or publicly display the Materials without prior written consent. Certain products are subject to the terms and conditions of Xilinx's limited warranty, please refer to Xilinx's Terms of Sale which can be viewed at <http://www.xilinx.com/legal.htm#tos>; IP cores may be subject to warranty and support terms contained in a license issued to you by Xilinx. Xilinx products are not designed or intended to be fail-safe or for use in any application requiring fail-safe performance; you assume sole risk and liability for use of Xilinx products in such critical applications, please refer to Xilinx's Terms of Sale which can be viewed at <http://www.xilinx.com/legal.htm#tos>.

Automotive Applications Disclaimer

XILINX PRODUCTS ARE NOT DESIGNED OR INTENDED TO BE FAIL-SAFE, OR FOR USE IN ANY APPLICATION REQUIRING FAIL-SAFE PERFORMANCE, SUCH AS APPLICATIONS RELATED TO: (I) THE DEPLOYMENT OF AIRBAGS, (II) CONTROL OF A VEHICLE, UNLESS THERE IS A FAIL-SAFE OR REDUNDANCY FEATURE (WHICH DOES NOT INCLUDE USE OF SOFTWARE IN THE XILINX DEVICE TO IMPLEMENT THE REDUNDANCY) AND A WARNING SIGNAL UPON FAILURE TO THE OPERATOR, OR (III) USES THAT COULD LEAD TO DEATH OR PERSONAL INJURY. CUSTOMER ASSUMES THE SOLE RISK AND LIABILITY OF ANY USE OF XILINX PRODUCTS IN SUCH APPLICATIONS.

© Copyright 2014 Xilinx, Inc. Xilinx, the Xilinx logo, Artix, ISE, Kintex, Spartan, Virtex, Vivado, Zynq, and other designated brands included herein are trademarks of Xilinx in the United States and other countries. All other trademarks are the property of their respective owners.